FACESHIELDS/PPE SOLUTIONS

FROM PLASKOLITE



DISPOSABLE FACE SHIELD SOLUTIONS FROM PLASKOLITE

TRANSPARENT, RELIABLE PROTECTION FROM SPLASH, PARTICLES AND FLYING DEBRIS





Replaceable clear shields of polycarbonate and PETG keep healthcare workers and patients safe. We produce TUFFAK Polycarbonate and VIVAK PETG Thin Gauge Sheet to support face shield requirements.

These products are:

- » High clarity
- » Easy to clean*
- » Bendable
- » Cut to size with standard tools
- » Able to be run to size call for details
- » TUFFAK Polycarbonate sheet complies with ANSI Z87.1 face shield protection at 0.040" and thicker
- » VIVAK PETG sheet complies with ANSI Z87.1 face shield protection at 0.042" and thicker

*See page 2 for more information on sanitizing and disinfecting thermoplastics



FACESHIELDS/PPE SOLUTIONS

FROM PLASKOLITE

DISINFECTING ACRYLIC, POLYCARBONATE AND PETG

When disinfecting OPTIX[®] Acrylic, TUFFAK[®] Polycarbonate and VIVAK[®] PETG, proper procedures should be taken. To minimize the risk of damage, use only compatible household cleaners as outlined below. For more details please contact the Plaskolite Technical Service Group at **800.848.9124** with any questions.

Product/ Compatibility** Manufacturer **Products** Brand TUFFAK sBioMed, LLC Steriplex SD Compatible TUFFAK Safetec of America Safetec surface wipes Compatible TUFFAK **CONTEC Healthcare** Peridox RTU Compatible TUFFAK **CONTEC Healthcare** Prosat sterile wipes PS-911EB Compatible TUFFAK Generic Hydrogen peroxide 3%-5% Compatible TUFFAK Generic Isopropyl alcohol 70% Compatible TUFFAK Contec Sat - Can 120 Satwipes (IPA) Generic Compatible TUFFAK Warm dish washing soap solution Generic Compatible OPTIX Hydrogen peroxide 3%-5% Generic Compatible OPTIX Generic Bleach - household laundry grade Compatible OPTIX Generic Compatible Quaternary ammonium compounds @ use dilution OPTIX Isopropyl alcohol - diluted with water to 30% strength Generic Compatible OPTIX Generic Vital oxide Compatible OPTIX Generic Warm dish washing soap solution Compatible VIVAK Hydrogen peroxide 3%-5% Compatible Generic VIVAK Generic Isopropyl alcohol 70% Compatible VIVAK Vital oxide Compatible Generic VIVAK Generic Contec Sat - Can 120 Satwipes (IPA) Compatible VIVAK Generic Warm dish washing soap solution Compatible TUFFAK The Clorox Company Clorox® health care bleach germicidal cleaner Not Compatible TUFFAK Unimed Corp Accel TB Not Compatible TUFFAK The Clorox Company Clorox® broad spectrum quaternary disinfectant cleaner Not Compatible TUFFAK Zep Inc ZEP 40 Not Compatible TUFFAK Zep Inc **ZEP Spirit II** Not Compatible TUFFAK PDI Inc PDI Super Sani-Cloth Not Compatible TUFFAK **Reckitt Benckiser** Lysol disinfectant spray brand III original Not Compatible TUFFAK Fiberlock Technologies Inc Shockwave disinfectant Not Compatible TUFFAK **CONTEC Healthcare** Preempt RTU multi-surface disinfectant cleaner Not Compatible TUFFAK The Clorox Company Clorox® household bleach - all dilutions Not Compatible OPTIX Generic Ethyl alcohol - pharmacy grade Not Compatible

Disinfectants for Plaskolite Products

SPECIAL NOTES: Cleaning products were tested on flat, unstressed, uncoated TUFFAK Polycarbonate, OPTIX Acrylic and VIVAK PETG sheet products. Do not use incompatible cleaners or disinfectants on sheet products. Generally speaking, soap and water or hydrogen peroxide disinfectants work best on these products. **Manufacturers may change their formulas without notification. Compatibility in perpetuity can not be presumed.

CURBEL

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use are beyond our control. We recommend that the prospective user determine the suitability of our materials and suggestions before adopting them on a commercial scale.



Curbell Plastics is a proud supplier of Plaskolite materials

1-888-CURBELL

400 W Nationwide Blvd, Suite 400 Columbus, OH 43215 800.848.9124 • Fax: 877.538.0754 plaskolite@plaskolite.com www.plaskolite.com